Embedding it better...



**µTasker Document** 

• AT91SAM7X Tutorial – Ethernet and the Simulator

# **Table of Contents**

1. Introduction	3
2. Getting Started	4
3. Testing on the Target	12
4. Compiling the Project for the Target	12
4.1. Compiling with GCC	14
5. Downloading the Code to the Target	15
6. Specific Notes concerning the AT91SAM7X	16
7. A Tour through the Demo Web Server	17
7.1. Menu	17
7.2. LAN configuration	19
7.3. Serial Configuration	21
7.4. Statistics	22
7.5. I/O Page	23
7.6. Administration Side	23
7.7. LCD Side	25
7.8. Email Configuration Side	26
7.9. Dynamic Content Generation Side	27
8. Developing – Testing - Debugging	28
9. Off-Line Simulation	34
10. Conclusion	36

# V1.4

# 1. Introduction

 $\mu$ Tasker is an operating system designed especially for embedded applications where a tight control over resources is desired along with a high level of user comfort to produce efficient and modular code.

The operating system is integrated with TCP/IP stack and important embedded Internet services alongside device drivers and system-specific project resources.

 $\mu$ Tasker and its environment are essentially not hardware specific and can thus be moved between processor platforms with great ease and efficiency.

However the  $\mu$ Tasker project setups are very hardware specific since they offer an optimal pre-defined (or a choice of pre-defined) configurations, taking it out of the league of "board support packages (BSP)" to a complete "project support package (PSP)", a feature enabling projects to be greatly accelerated.

This tutorial will give you a flying start to using the µTasker on the ATMEL AT91SAM7X. It can be fully simulated using VisualStudio 6.0 or higher and can be run on the various common evaluation boards (specific configurations for the ATMEL AT91SAM7X-EK and OLIMEX SAM7X-EX256 are discussed in more detail), for which Rowley CrossWorks, IAR, Keil uVision and GCC project configurations are available. Building the project using GCC is included as an optional post-build step when working in VisualStudio, but debugging with the GNU tool chain is not discussed. Generally a JTAG debugger should be used together with the chosen development environment. When no target debugging is involved, the generated code can also be loaded via the debug port or USB with the ATMEL SAM-BA program, which is detailed later on in the tutorial.

This tutorial uses the IAR compiler to illustrate building the project for the target but other compilers and their environments are basically equivalent.

Therefore there should be nothing standing in your way to getting your first, powerful embedded IP project up and running.

This version of the SAM7X tutorial has been adapted for the  $\mu$ Tasker V1.4 version including new graphical LCD support, which is also illustrated here.

For more µTasker documentation, including a guide to using the USB capabilities of the SAM7X project visit: <u>http://www.utasker.com/docs/documentation.html</u>

Note further that MODBUS support (serial and TCP) is available as an extension pack for the SAM7X – see the MODBUS user's guide for full details: <u>http://www.utasker.com/docs/MODBUS/uTasker\_MODBUS.PDF</u>

#### V1.4

# 2. Getting Started

You are probably itching to see something in action and so why hang around. Let's start with something that will already impress you and your friends – no simple and basically useless demo which blinks an LED in a forever loop but something seriously professional and for real life projects very handy.

First I will assume that you have VisualStudio installed on your PC since we will first simulate everything – but don't worry, we are not going to see something attempting to interpret the instructions of the processor and requiring 2 minutes to simulate a couple of seconds of the application, instead we will see your PC operating in "real time" as the target processor. Your PC will not realise that the processor is simulated and so when you try contacting it by pinging it or browsing to it with your web browser, we will see that your PC will sends IP frames to the network and will see answers on the network from the simulated device. Other PCs or IP enabled embedded devices on the network (as well as further simulated devices) will also be able to communicate with this simulated device. You can also capture the frames using a sniffer tool (we will use Wireshark) for further analysis and playback.... Getting excited? In a few minutes you will see it in action!

If you haven't VisualStudio (6.0 or newer) then there are trial versions and the free Express version [http://msdn.microsoft.com/vstudio/products/trial/or http://www.microsoft.com/express/] and you can probably pick up a 6.0 version for very little cash on Ebay. VS 6.0 is adequate for our work as are the Express editions. It contains a world class C-compiler and editor as well as loads of other tools which make it a must, even for embedded work.

The simulator requires also WinPCap to be installed (from <a href="http://www.winpcap.org">http://www.winpcap.org</a>) which is an industry-standard tool for link-layer network access in Windows environments. It is also used by the network sniffer Wireshark, which every Ethernet designer really should have. Therefore it is simplest to install Wireshark since this includes WinPCap, saving a step, and making for simplest installation. Wireshark can be downloaded from <a href="http://www.wireshark.org/">http://www.wireshark.org/</a> and is discussed towards the end of the document.

If you don't want to see the simulator in action – which would be a big mistake as you will miss the opportunity to save many hours of your own project time later – there is target code which can be loaded to the target and will also run. This is also detailed later on in the tutorial.

You will find that the simulator is useful for most real embedded work. First, it allows testing things which you may not already have available as hardware (even if you have no evaluation board and cross compiler for it yet, you can start writing and testing your code) – it will allow you to use a matrix keyboard, LCDs, I<sup>2</sup>C EEPROM or SPI FLASH (and more) connected to the virtual target without having to get your soldering iron out to connect it. And it is so accurate that you can then cross compile to the target and it will (almost certainly) work there as well. This is the last time I will say it ... *don't make the BIG MISTAKE of taking a short cut when starting and diving into coding on the target*. If you are an embedded SW professional you will be missing the chance of saving enough time in a year for a couple of months extra vacation. If you are a hobby user, you will be missing the change to get out more...!

So...

#### ...fasten your seat belts since we are about to roll

- 1. Simply copy the complete μTasker folder to your PC and go to \Applications\uTaskerV1.4. This is a ready to run project directory showing a useful application using network resources (and more).
- 2. Move to the sub director Simulator and open the VisualStudio project workspace uTaskerV1-4.dsw. This project is in the VisualStudio 6.0 format to ensure compatibility and, if you have a higher version, simply say that it should be converted to the new format no problems are involved and it should build with no warnings.
- 3. Ensure that the compiler is set up for the SAM7X target in the project's pre-compiler settings: look for the pre-processor define \_HW\_SAM7X. If instead you find that the project is set up for another target, eg. \_HW\_NE64 or \_M5223X simply overwrite this with \_HW\_SAM7X.

Ensure that the project is configured for your target board in config.h: enable either SAM7X\_EVAL if you are using the ATMEL evaluation board, or else OLIMEX\_EX256 for the demo board. *Further boards can be added later if necessary to suit your own hardware*.

Build the project (use F7 as short cut) and you should find that everything compiles and links without any warnings.

Note that the VS project as delivered has two configurations (uTasker - Win32 debug and uTasker - Win32 uTasker SAM7X plus GNU build). When the configuration with GNU build is selected a post build step will cross compile the project code using the GCC compiler. This is only possible when the GNU compiler is installed on the local PC and it may also be necessary to modify the paths in the bat file \Applications\uTaskerV1.4\GNU\_SAM7X Build\_SAM7X.bat to suit. This is discussed in more detail in chapter 4.1.

4. I would love to be able to say "Execute" but there are a couple of things which have to be checked before we can do this. First of all, you will need to be connected to a network, meaning that your PC must have a LAN cable inserted and the LAN must be operational – either connected to another PC using a crossover cable or to a router or hub (wireless links tend not to work well but this may improve as the WinPCap capabilities get better with newer version).

Then we have to be sure that the network settings allow your PC to speak with the simulated device. The IP address must be within the local subnet:

Open the C-file application.c in the uTaskerV1.4 project directory and check that the following default settings match your network settings (check what your PC uses in a DOS window with "ipconfig")

Just make sure that the network mask matches, that the device's IP address is within the local network and that the IP address defined doesn't collide with another one on the local network.

After making any modifications, simply compile the changes and we will be in business.

5. So now I can say EXECUTE (use F5 as short cut).

You will see the simulated device working away on your PC screen. If the define SUPPORT\_GLCD hasn't been removed in config.h there will also be a simulated graphic LCD displaying some images. *This should be removed later for testing on the target if there is no graphical LCD actually connected*. There will also be one port output toggling away. Let's take a quick look at it. This is in fact the watchdog routine which is called every 200ms which is also toggling the output so that we can see that all is well (PB19]).



Figure 1. µTasker simulator running

If you hover your mouse over the port which is toggling, or other available ones, you will see which pin number it has on the device, its name and present use as well as the possible peripheral functions which it can be programmed to perform. In the screen shove above this is seen by the line in blue at the bottom of the simulation window.

Open the file uTasker\Watchdog.c (in the VisualStudio project manager). Put your cursor on the call to retrigger the watchdog "**fnRetriggerWatchdog**()" and hit the F9 key (*set a break point*). Almost immediately the program will halt and you can use F11 to step into the hardware specific routine responsible for triggering the watchdog and in our case also toggling the port output. The routine writes to the corresponding device registers and returns. Remove the breakpoint and let the simulated device run again using F5.

6. OK. So at least you are convinced that it is really running our project code, but it is not exactly something to write home about.

Let's get down to more serious stuff:

There are some menu items in the  $\mu$ Tasker environment simulation window. Open "LAN | Select working NIC" and select the network card you would like the simulator to use – don't worry, it will be shared with anything else which is already using it.

Open a DOS window and do the standard PING test - "ping 192.168.0.3" if you didn't need to change anything, or the IP address you defined if you did.

The simulated device should now be responding. That means that your PC has sent PING test messages to the network and received answers from some network device (or course our internal simulated device – but no one will know the difference). You can also try sending the ping test from another PC on the network and it will also receive an answer.

If you have a network sniffer you can also record the data from the network – don't worry if you haven't used a network sniffer before because we will come back to this later on and use Wireshark to do the job.

Watch the LAN indicators on the processor's virtual LAN connector. The left one will blink green when a frame is received – if it is accepted by the device (matching address, broadcast or all when in promiscuous mode). The right one will blink red whenever the simulated device sends a frame to the network.

7. I suggest that you now close the  $\mu$ Tasker environment simulation window using the 'normal' method <u>File</u> | Exit or by clicking on the close cross in the top right hand corner.

This standard termination will cause the selected NIC to be saved to a file in the project simulation directory called **NIC.ini** and so you will not have to configure it the next time you start the  $\mu$ Tasker environment simulation.

8. Now I'm sure you are not yet satisfied with the progress, so let's execute the project again (short cut F5) and this time we will do something a bit more interesting. Start your web browser (Internet Explorer, Firefox, Chrome, etc.) and establish a connection with the simulated target: In the URL line type in <a href="http://192.168.0.3">http://192.168.0.3</a> (assuming its address has not been changed) and hit the ENTER key. The web browser will request the start page on the web server, which will return the following page the first time used:



Figure 2. µTasker web server displaying that it has no web pages loaded

This is displaying that the page has not been found on the server, which is simply due to the fact that we haven't loaded any web pages to it yet, so we will do this as next step.

Note however that the web browser is displaying the AT91 favicon. This is because this favicon is embedded in the code and not in the  $\mu$ FileSystem – this is explained in detail in the user file document

http://www.utasker.com/docs/uTasker/uTaskerUserFiles.PDF

9. Take a look in the project directory

\Applications\uTaskerV1.4\WebPages\WebPagesSAM7X and you will find the web pages prepared for the demo project. These are HTM, JPG and GIF files. It is possible to load these pages using FTP clients but these tend to work quite differently from another and require various setups before they work smoothly. See the following document for more information on this subject: http://www.utasker.com/docs/uTasker/uTaskerFTP.PDF

This is the reason that working with simple DOS FTP tends to be the fastest and simplest method and the bat file  $Copy_all.bat$  even does all the work for you. Check that its content is set to use the correct IP address and then double-click the bat-file to start the transfer of all of the web pages to the simulated target device. The transfer takes just a few seconds.

Then go back to the web browser window and make a refresh. Now you will see the start side and can navigate to a number of other pages.

Before we get into any more details about the web pages and their uses, please modify and save the Device ID (on the start page – default "uTasker Number 1") to any name of your choice and close the  $\mu$ Tasker environment simulation window by using the 'normal' exit method.

By doing this, the contents of the device's simulated FLASH (Flash is used to save the web pages in the  $\mu$ FileSystem and also any parameters, for example the device ID which you have modified) are saved to a file in the project simulation directory called **FLASH\_SAM7X.ini**.

Now execute again (F5) and check that the loaded web pages are all there and that after a refresh of the start side also the device ID which you chose is correct. Now you should understand the operation of the simulator; *on a normal exit it saves all present values and settings and on the next start the device has the saved FLASH contents as at the last program exit.* This is exactly how the real device works since, after a reset, its FLASH contents are as saved – I mean, that is what FLASH is all about.

If however you have modified FLASH contents and do not want them to be saved, you can always avoid this by quitting the debugger (short cut SHIFT F5) which causes the simulator to be stopped without performing the normal save process. If you wish to start with a fresh device (with blank FLASH contents) then simply delete the **FLASH\_SAM7X.ini** file from the simulator directory...

10. There is one important setting which we should perform before continuing; that is to set a MAC address to our new device.

So browse to the "*LAN configuration side*", where you will see that the default MAC address is 00-00-00-00-00. This works, but we really should set a new one – as long as we are not directly connected to the Internet any non-used value can be set. You make one up. For example set 00-11-22-33-44-55 (watch that the entry format is correct and always start with 00!) and then click on "modify / validate settings". The entry field will be set inactive since it is no longer zero and cannot be changed a

second time (should your want to reset the value before we commit it to (simulated) FLASH click on "*Reset changes*", otherwise click on "*Save changes*".

The device is commanded to be reset at this point after a short delay of about 2 seconds to allow it to complete the web page serving. The simulator will open a dialog box to indicate that it has been terminated with a reset:



Figure 3. µTasker simulator indicating that the processor has just been reset

You can restart the simulator after the reset (which was interpreted as a 'normal' program exit and so the changes to the FLASH have also be saved to the hard disk and will be restored on the next program start) by using F5 as normal.

11. You may have read on the LAN configuration side that the new setting should be validated within 3 minutes – this is a safety mechanism so that falsely set critical values do not leave a remote device unreachable and means that we should establish a connection within three minutes of the new start to verify that all is well, otherwise the device will automatically delete the newly set values, reload the original ones and can then be contacted as before, using the original settings. So we will now validate our new setting (new MAC) so that it will always be used in the future.

Refresh the web pages by clicking first on "*Go back to menu page*" and then "*Configure LAN Interface*" again.

You may well have a shock because it doesn't respond....but don't get worried because your PC may still be trying to reach the IP address using the previous MAC address, which is no longer valid (hence an incorrectly configured device can become unreachable). In a DOS windows type in "arp –d" which will delete the PC's ARP table – which is mapping IP address to MAC addresses and then it will work on the second attempt. Vista PCs may not always accept this command so wait a couple of minutes before starting the simulator again, until its ARP table automatically times out.

The page will not allow any parameters to be modified and also the check box "*Settings validated*" shows that the device is waiting for the new values to be validated. To perform this, click on "*Modify / validate settings*", after which the parameters will be displayed as validated. (*Don't forget to terminate the simulator normally later so that it is really the case*).

Should the 3 minutes have elapsed before you managed all that, the simulated device will again reset, clearing the temporary settings and reverting back to the initial

MAC address. Just start the simulator again and repeat this step. While the project is waiting for the critical network changes to be validated you will notice that the LCD doesn't display anything. As soon as the validation sequence has been completed also the LCD display demonstration will start running as normal.

12. Now you may be thinking that it is all well and good having a web server running on a device, sitting somewhere on the Internet but you probably want to use the device for controlling something - in its simplest form by switching something on or off. Using a relay this could be something quite powerful which can also have really useful benefits; imagine browsing to your device and commanding it to open the blinds or turn on the lawn sprinkler...the list of possibilities is almost endless... Look at the simulated AT91SAM7X and imagine that you have connected your lawn sprinkler to the output Port PB22. Presently it is at the state input '1' [signified by '^'], the default state when the software starts since there is a pull-up in the device. Now click on the link menu page to "Open an I/O window" – it is shown in the following screen shot. Notice that the port PB22 is being displayed as an input and its digital value as active ('1') in its check box.



Figure 4.  $\mu$ Tasker web server showing the I/O control page

Do a quick test: Hover your mouse over the port PB22 in the simulator – it will tell you which pin it is on your device. Now click – this has toggled the simulated input (each time you click, it will change state again) – leave it at the low state '0', displayed as 'v'. Now refresh the I/O web page by clicking in the Refresh button.

What is the web page now displaying? If it is behaving correctly it will of course be displaying the new port input state.

Now we can configure it as an output and control its state from the I/O page:

Set PB22 to be an output, rather than an input and click on "*Modify configuration*". Afterwards set the port state to '1' by setting the first port value from the left and click on "*Modify outputs*". Watch the state of Port PB22 on the simulated device – you will see that the output is now set and now your lawn would get the water it has been waiting for!

Set the state to '0' and it will be turned off. In this example web page, all of the 4 Ports PB22..PB19 outputs can be controlled individually.

PB19 is used as a RUN LED in the demo project and so is configured as an output by default, as is PB20.

If you would like a certain setting to be returned after every reset of the device, simply save the setting by clicking on "*Save settings as default configuration*" and you will see that they are indeed set automatically when the device is started the next time.

The demo project includes also 16 user controllable outputs. These are automatically configured as outputs in the project code and can be seen as outputs with state '0' when looking at the simulator. If you now click on the user defined outputs on the I/O page you will see that they immediately toggle their port output and the state is either displayed as a grey button when '0' or as red buttons when '1'. Also the present state of the 16 outputs can be saved as default states when the target starts the next time. Note that these outputs can be mapped to any port and port bit in the demo project – it shows a useful example of flexible independent output control. Note also that the outputs 1, 2, 3 and 10 are used by the LCD interface and so cannot

be modified when the graphical LCD is defined.

13. The last setting which we will change before taking a look at the project on the target hardware is to activate HTTP user authentication and disable the FTP server so that no one else without our password has entry to the web server and no sneaky person can change the web pages which we have just programmed...

Browse to the administration page, deactivate FTP and activate HTTP server authentication before selecting the action to "*Modify and save server settings*". Finally click on "*Perform desired action*" and close your web browser..

Open the web browser again and enter the device's address <u>http://192.168.0.3</u> (or your address) and this time you will need to enter the user name "ADMIN" and password "uTasker" to get in.

Try to do something with the FTP server (like transfer the file with *Copy\_all.bat* or delete the file system contents with delete\_all.bat) and you will find that it simply won't work anymore. This is because the FTP server is no longer running in the simulated device and you can rest assured than no one out there will be able to change anything which you have loaded.

You probable noticed a button at the bottom of the administration page which allows a file to be searched for and uploaded to the target as a new software version. This is an example of using the HTTP POST method to transfer data to the embedded device. The  $\mu$ Tasker project for the SAM7X supports the upload of complete new

software using this method (as well as by FTP and even USB). For further details about using this capability on the SAM7X see the document http://www.utasker.com/docs/uTasker/BM-Booloader for SAM7X.PDF :You will see that you will then be able to develop code for a real target on the internet, including uploading it from anywhere where you have web access to it!

I hope that the introduction has shown that we are dealing with something which is very simple to use but is also very powerful in features. There are lots of details which need to be learned to understand and use everything to its fullest capabilities and it is up to you to decide whether you want this or would like to simply use the µTasker and its capabilities as a platform for your own application development. In any case you have just learned the basics of a powerful tool which is not only great fun but can really save you lots of development time.

# 3. Testing on the Target

Up until now we have been using the simulator and hopefully you will agree too that it is a very useful tool. We have tested some guite useful code designed to run on the SAM7X and done this in an environment enabling us to do embedded IP stuff in real time. We haven't actually done any debugging or added new code but you can probably already imagine the advantages of being able to write and test it on the PC before moving to the target.

At the same time you are probably thinking about how that will all work on the real device. Perhaps you are worried that it is all a show after all and the real device will remain as dead as a door nail or at the best crash every time the user breaths heavily. So let's prove that this is not the case by repeating the first part of the tutorial, but this time we will go live...

We will use the ATMEL AT91SAM7X-EK or the OLIMEX SAM7X-EX256 (both will operate equivalently).

# 4. Compiling the Project for the Target

Warning: the µTasker demo project V1.4 is delivered with graphical LCD support activated. This can cause the SW to hang if there is no real LCD connected. Before compiling for the target it is recommended to disable SUPPORT GLCD in config.h so that this cannot occur.

The first thing that we need to do is to compile the project for the target. This means that we will be cross compiling the code which we already have been testing with the simulator, using an assembler, a C-compiler and a linker. There are a number of such tools available and unfortunately they are not all compatible in every aspect, even if ANSI compatible. Basically there is always the chore of getting the thing to reset from the reset vector, meaning that the start-up code must be available and at the correct location. Then there are specialities concerning how we force certain code or variables to certain addresses or regions and how we need to define interrupts routines so that they are handled correctly. Sometimes there is also need for some special assembler code which does such things as setting the stack pointer or enabling and disabling interrupts.

The µTasker demo project for the SAM7X is delivered with projects for IAR Embedded Workbench (IAR4 and IAR5), Keil uVision3, Rowely Crossworks and a standalone GNU makefile. The IAR and Keil compilers are very good compilers, producing highly efficient uTaskerV1.4 SAM7X.doc/0.03

code so are recommended for professional work as is Rowley Crossworks if the GCC compiler is preferred. There are evaluation versions available from all suppliers - which are generally time or code size limited - for anyone wanting to get a feel for the product, otherwise it should be possible to get the code up and running with any other compiler without too much hassle, but it will involve setting up an equivalent project.

By the way, if you can't wait until you have installed the compiler or got your own project up and running, there are files delivered with the  $\mu$ Tasker which were compiled with the IAR and GCC compilers and can be downloaded already...

You can find the project file and the target file(s) in the sub-directory called IAR\_SAM7X:

uTaskerV1.4.eww This is the IAR Embedded Workbench project work space

Applications\uTaskerV1.4\IAR\_SAM7X\Release\Exe\uTaskerV1.4\_AT91SAM7X -EK.bin This is the file which you can download to an ATMEL AT91SAM7X-EK evaluation board using SAM-BA

Applications\uTaskerV1.4\IAR\_SAM7X\Release\Exe\uTaskerV1.4\_SAM7X-EX256.bin This is the file which you can download to an OLIMEX SAM7X-EX256 evaluation board using SAM-BA

When the release target is compiled it normally produces the output Applications\uTaskerV1.4\IAR\_SAM7X\Release\Exe\uTaske rV1.4.bin

Using the IAR Embedded Workbench you can open the µTasker project and compiler either for use with the debugger or as a release version (**Project** | **Edit Configurations...** - **debug** or **release**).

The debug project can be downloaded using a JTAG debugger to the internal SRAM of the SAM7X on the evaluation board (with 64k SRAM available it can run the  $\mu$ Tasker demo project as long as not all options are active). The release project generates code for operation from internal FLASH and can best be downloaded using the SAM-BA program from ATMEL, which will be detailed a little later on.

## 4.1. Compiling with GCC

The project is delivered with a bat file and make file so that the project can be simply compiled with the GNU compiler. It is recommended to use the Codesourcery  $g_{++}$  build, which is available as a free Lite edition at <u>http://www.codesourcery.com/</u>

Compiling with GCC is also greatly simplified when working from VisualStudio by adding the step as a post build step to the normal simulator compile process. When the target Win32 uTasker SAM7X plus GNU build is selected as active configuration the process will be executed as follows:

- The GCC directory GNU\_SAM7X contains the bat file Build\_SAM7X.bat. This directory will be selected as working directory
- The bat file will be executed and starts the GCC make file make\_uTaskerV1.4\_GNU\_SAM7X. The bat file also contains a path to the GCC binaries on the local PC – *if no path variables have been configured when the GCC compiler was installed this path can be set manually to enable the make utility, compiler and linker to be found.*

The following target files are generated during the GCC build step:

- uTaskerV1.4.s19: this is a stand-alone target in SREC format
- uTaskerV1.4.bin: this is a stand-alone target as binary file
- uTaskerV1.4\_BM.s19: this is a boot loader compatible application in SREC format
- uTaskerV1.4\_BM.bin: this is a boot loader compatible application as binary file
- uTaskerBM.bin: this is a target containing boot loader and boot loader compatible application in binary format.
- H\_Upload.bin: this is an application which can be uploaded via web browser. See the μTasker 'Bare-Minimum' boot loader documentation for more details.

The stand-alone target can be used for first tests since it doesn't require a boot loader to be compiled and installed.

Pre-built release images can be found in the GCC directory as follows:

Applications\uTaskerV1.4\IAR\_SAM7X\Release\Exe\uTaskerV1.4\_AT91 SAM7X-EK.bin

Applications\uTaskerV1.4\IAR\_SAM7X\Release\Exe\uTaskerV1.4\_SAM7 X-EX256.bin

The GCC build is displayed in the log windows of VisualStudio and warnings or errors are counted by the VisualStudio compiler during the process.

# 5. Downloading the Code to the Target

The following explains how to download the FLASH based target code to the ATMEL AT91SAM7X-EK using the SAM-BA utility from ATMEL.

The SAM-BA utility can be downloaded from the ATMEL web site <u>http://www.at91.com/</u> as part of the AT91-ISP tool package. Once you have installed the tool package you can start. Here's a set by step guide so that it should work with no hassles the first time for you:

- Step 1: Connect a cross over cable between the ATMEL AT91SAM7X-EK connector labelled SERIAL DEBUG PORT and a COM port on your PC. The cross over cable is delivered with the evaluation board.
  Alternatively connect the USB device connector to a free USB socket on the PC – this will only work when the SAM7X is fully erased; see Step 3 if this is not yet the case and then return to step 1.
- Step 2: Power on the evaluation board its power LED should light. Power can be supplied via USB cable.
- Step 3. Short circuit the jumper marked ERASE. This will cause the complete internal FLASH to be erased so that we know that everything is fresh and that all NV bits (non-volatile flag bits) in the device have been reset. Reposition the jumper as it originally was (connected to only one of the two pins) and reset the board.
- Step 4. Start the SAM-BA program and select the COM port which you have connected and the target AT91SAM7X256-EK. (If you have connected via USB it will display the USB interface as alternative, possibly as virtual COM port depending on the operating system used). Then start the connection by clicking on "Connect".
- Step 5. Assuming the connection is successful you will see a window allowing you to display the internal memory contents of the device and also load new code to FLASH. Fill out the file to be loaded in "Send File Name" and then start by clicking on "Send File".

The loading takes several seconds after which the tool will ask you whether you want to lock regions in the FLASH. Answer with "NO".

Step 6. Although the program has been loaded into the internal FLASH of the SAM7X you would find that it can still not run. The reason is that the device will still boot into its SAM-BA debug program and not to our code.

To arrange for your board to actually boot from the new code it is necessary to program a NV bit. To do this, use the "Script" called "Boot from FLASH (GPNVM2)" and execute it. This will program the corresponding bit to the correct state so that our code will actually start.

Step 7. Quit the SAM-BA program and reset the evaluation board. You will see that it is now running the μTasker demo program!!

Since the FLASH was completely deleted, it will start using default parameters and have no web pages loaded. Therefore you will have to repeat the steps in the tutorial, after which the web server will be complete.

You should be done within a few minutes....

Are you surprised that it behaves the same as the simulator? You shouldn't really be because that is exactly what the simulator is all about. It allows you to test your real code in real time and once it is working as you want it to, then you can transfer it to the real target. In fact you will find that your real target is not really necessary for most of your development work. Develop on the simulator and ship on the target – that is the way to do things really efficiently.

Note that the I/O page allows the LEDs and port lines on the I/O port connector on the ATMEL AT91SAM7X-EK to be controlled and the state of these to be displayed. Two LEDs are set as outputs be default. If PB19 is reconfigured to be an input the blinking LED will no longer light.

# 6. Specific Notes concerning the AT91SAM7X

The demo project is designed to work on the SAM7X512, SAM7X256 and the SAM7X128. For this reason the memory map is set up to use only the SAM7X128 resources. The memory map thus has the following construction.

```
0xfffffff - end of memory space
0xfffa0000 - Start of internal peripherals
0x00207fff - SRAM end { 32k }
0x00200000 - SRAM start
0x0011ffff - FLASH end { 128k }
0x00100000 - FLASH start
0x0001ffff - FLASH end { FLASH ACCESSIBLE ALSO HERE }
0x00000000 - FLASH start { FLASH ACCESSIBLE ALSO HERE }
```

If larger chips are used this can be modified to make use of the larger internal resources that are available.

# 7. A Tour through the Demo Web Server

Now that you have the possibility to simulate the demo and also run it on the target hardware it is time to take a more detailed look at what it does and then how it all works. The demo is designed to give you a practical platform to use as a basis for your own developments so it would be good to know how it can be best modified to suite your own needs.

### 7.1. Menu



Figure 5.  $\mu Tasker$  web server showing the menu page

**Serial number** – this is a decimal representation of the MAC address programmed in the device. Since the MAC address is normally unique it can serve also as a serial number if required. Notice that the serial number is displayed in grey and cannot be modified (disabled).

**Software version** – this is a string which is defined in application.h. It is also disabled so that it cannot be modified via the web side.

**Device ID** – this is a string defined in the cParameters structure in application.c. The default value can be set in code and also modified via the web page. When '*Save new device ID*' is clicked, the new value is also saved to a parameter block in the internal flash so that it remains valid after the next reset or power up.

*Menu* – There are links to several other web pages allowing specific configurations to be displayed and modified.

**Email address** – If you have configured the demo project to support SMTP (#define USE\_SMTP in config.h) then it is possible to enter an email address and send a test email to it. This entry is disabled if the support is not active in the project.

Note that it is necessary to configure some SMTP settings before an email can actually be sent – the default settings will not work since they are fictive and will not correspond with your email provider. Full details to the SMTP and its use in the  $\mu$ Tasker demo project are given in the document <u>http://www.utasker.com/docs/uTasker/uTaskerSMTP.PDF</u>

**Logo and upload field** – The  $\mu$ Tasker logo was uploaded to the file system as a GIF file when the files were loaded. It is possible to change this logo for a different GIF file by selecting a GIF and pressing the "*Upload now*" button. The GIF may be up to 6k in size.

## 7.2. LAN configuration

This side is a very critical side since it allows important Ethernet settings to be modified. The first time the device is started, the default MAC address – defined in the cParameters structure in **application.c** - is 0-0-0-0-0. It can be changed just once, after which it is displayed as disabled. This is because it is normally necessary to program a new device with a unique MAC address which should normally never be changed again. (*See the short discussion about MAC addresses at the bottom is this section for some details about how they are obtained*.)

The IP address, subnet mask and default gateway IP address can be modified as long as the device is not set to DHCP operation. If they are first modified and then the device is set to DHCP mode, they represent preferred settings to be requested during the DHCP procedure or for use as a last resort if no DHCP server is available.

le <u>E</u> dit <u>V</u> iew Hi <u>s</u> tory <u>B</u> ookmark	s <u>I</u> ools <u>H</u> elp http://192.168.0.3/4Lan.htm $\reltarrow \ \Box = \Box \cdot$	Google 🌙
	Ethernet Settings	<b>d</b> 5 M
Setting	Value	Modified
MAC address	00-11-22-33-44-55	
IP address	192.168.0.3	
Subnet mask	255.255.255.0	
Gateway IP address	192.168.0.1	
Ethernet speed	100M 🔘 10M 🔘 Full-Duplex 🗌 Auto-negotiate 🔍	
Configure using DHCP server	(set IP to 0.0.0.0 if no preferred setting)	
Settings validated	When not set, the device is waiting for validation after a network setting change	ool
Modify / v Saving of new settings cause a other this ensures that	ralidate settings Reset changes Save changes* n immediate reset and must be validated within a period wise the original settings will be returned. t invalid settings do not render a device unreachable. <u>Go back to menu page</u>	of 3 minute

The Ethernet speeds of 10M, 100M or auto-negotiation (full or half-duplex) can be set.

Figure 6. µTasker web server showing the LAN configuration page

Values, which are not disabled, can be modified and accepted by clicking on "Modify / validate settings" and changed values are indicated by a check box in the configuration table.

They have not yet been committed to memory and the previous setting can be returned by clicking on "Reset changes".

Once you are sure that the modifications are correct, they are saved to flash memory by clicking on "Save changes". This will cause also a reset of the device after a delay of about 1 second and it will be necessary to establish a new connection to the device using its new settings and validate the changes.

**So why make it so complicated?** Well it is simply to be sure that you have not modifying something which will render the device unreachable. For example, you may have changed its Ethernet speed from 100M to 10M although it is connected to a hub which only supports 100M and, to make matters worse, the device is not simply sitting on your office desk at arm's length but is at a customer's site several hours drive away. It would be a nasty situation if you had just lost contact with the equipment and have to somehow get it back on line although everyone at the customer's site has already left for a long weekend...

So this is where the validation part comes in. After the reset, the device sees that there are new settings in memory but also that these are only provisional (not validated) - the original values are also still available. These new values are nevertheless used for a 'trial-period' and a timer of three minutes duration started. It is now your job to establish a new web server connection to the device, using the new settings and to click on "Modify / validate settings". If you do this the check box names "Settings validated" will be checked, the new parameters are validated in flash and the old ones deleted. This in the knowledge that the new values are also really workable ones – how would you otherwise have been able to validate them?

Imagine however that a change really rendered the device unreachable – for example the LAN speed was really incompatible or you made a mistake with the subnet mask. After three minutes without validation, the provisional values are deleted from flash and, after a further automatic reset, the original settings are used again. After a short down period you can then connect as before the change and perform the modifications again, though correcting the previous mistake. There is therefore no danger of losing contact with the device, even when a 'silly' mistake is made.

#### Some notes about MAC addresses

If you are using your own device behind a router and it is not visible to the 'outside world' you can in fact program any MAC address that you like because it is in a private area. It just has to be unique in this private area. (This is also valid for a device sitting in a Demiliterized Zone- DMZ)

If however you are selling a product or the device is sitting directly on the Internet then it must have a world wide unique MAC address which has to be purchased from IEEE. It is purchased either as a block (IAB) of 4k MAC addresses at a cost of about \$500, or if you are going to produce a large number of pieces of equipment you can purchase a unique company ID (OUI) of 16Million for about \$1'600 (plus \$2'000 if you don't want the OUI to be registered on the public listing).

It is then your responsibility to manage the assignment of these addresses in your own products.

The registration page is at: http://standards.ieee.org/regauth/index.html

For any one just wanting to make one or two pieces of equipment for hobby use it is a bit much to pay \$500 for a bunch of MAC addresses and use just one or two of them. Unfortunately it is no allowed to sell the rest on to people in similar situation because a block must always remain with the individual or organisation purchasing it.

One trick which is often used is to find out what the MAC address is in an old NIC from an old PC which is being scrapped. This MAC address is then used in your own piece of equipment and the old NIC destroyed. You can then be sure that the MAC address is unique and can not disturb when used for any imaginable application.

### 7.3. Serial Configuration

This web page allows the debug interface UART in the SAM7X to be set. See the UART User's guide for some more details of this interface: <u>http://www.utasker.com/docs/uTasker/uTaskerUART.PDF</u>



Figure 7.  $\mu Tasker$  web server showing the serial interface configuration page

## 7.4. Statistics

The statistics window opens in a separate window and displays a table of the number of Ethernet frames counted by the Ethernet task. These are classified according to whether they were transmitted, received for the local IP address or received as broadcast frames and divided into IP protocol types. Since the values can continue to change, the user can update the window by clicking on the "*Refresh*" button. It is also possible to reset the counters if desired by clicking on "*Reset frame stats*".

The contents of the ARP cache is also displayed and can be cleared by clicking on "Delete ARP entries". These are equivalent to the DOS commands arp -a to display the local ARP cache and arp -d to delete it. Notice that when the ARP cache is deleted via the web page there will always remain one entry, this being the PC which commanded the deletion of the ARP table and updated the table. Due to the network activity it will always immediately be reentered...



Figure 8. µTasker web server showing the statistics page

### 7.5. I/O Page

The I/O window was discussed in step 11 of the tutorial and will not be discussed in any more detail here.

### 7.6. Administration Side

On this page the FTP server can be activated and deactivated. See also step 12 of the tutorial.



Figure 9.  $\mu$ Tasker web server showing the administration page

The HTTP server can be configured to require basic authentication, meaning that it requests the user name and password when a new connection is established. These values are contained in the default settings in application.c.

A TELNET server can also be enabled or disabled, including setting it to a particular port number.

The previous three settings are modified and saved by setting the desired action to "*Modify* and save server settings" and clicking on "*Perform desired action*".

A further action is "*Restore factory settings*" which returns the default settings as defined in application.c. This also provokes a reset of the device and if the default settings cause the network values to be modified it will automatically start a three minute validation period meaning that it will also be necessary to establish a connection using the 'factory settings' and validate them before the original ones will become permanent. This is again to ensure that there is no danger of losing contact with a remote device. Note that the MAC address is not reset since the Mac address should always remain unchanged in the device.

The last action is a simple reset of the device.

#### **Memory Utilisation**

**HEAP** – the used heap and the maximum defined heap are displayed. Note here that the simulator will often display that more heap is used as needed in the real target due to the fact that some variables will be of different sizes when running on a PC compared to an embedded target. It allows the real use on the target to be monitored and the user can then optimise the amount of heap allocated to just support the worst case.

**STACK** – the amount of stack which has not been used (safety margin) is measured and displayed. As long as the value remains larger than 0 the system is not experiencing any memory difficulties. A value of zero indicates a critical situation and must be reviewed. The simulator however doesn't perform this stack monitoring and will always display zero; its use is on the target where resources need to be monitored carefully.

The methods used for the memory monitoring are detailed in the  $\mu$ Tasker main documentation.

**Present Time** – If the demo project is configured to collect the timer from a time server, this displays the present time. The time may also be available if the device which the  $\mu$ Tasker is operating on processes a RTC.

**Running Time** - The time since the device started, or since the last reset, is displayed. This is useful when monitoring a remote device to ensure that it is indeed operating stably since a watchdog reset due to a software error would allow the device to remover but possibly not enable its occurrence to be readily detected.

#### Upload new software

See the following  $\mu$ Tasker documents for further details about using the firmware upload capabilities of the  $\mu$ Tasker project. This uses the HTTP post method to transfer new software to the target.

- <u>http://www.utasker.com/docs/uTasker/uTaskerBoot\_003.PDF</u>
- <u>http://www.utasker.com/docs/uTasker/BM-Booloader\_for\_SAM7X.PDF</u>

## 7.7. LCD Side

When the graphical LCD support is enabled (define SUPPORT\_GLCD in config.h). The LCD page will display the present LCD content. It also allows the user to post am image to be displayed on the graphical LCD.



Figure 10. LCD page showing the present LCD image

For full details about the graphical LCD support in the project please consult the LCD User's Guide at <u>http://www.utasker.com/docs/uTasker/uTaskerLCD.PDF</u>

## 7.8. Email Configuration Side

The standard set of web pages loaded to the SAM7X does not include a setup page for the SMTP server but an alternative page can be temporarily loaded to perform this. For more details see the document <a href="http://www.utasker.com/docs/uTasker/uTaskerSMTP.PDF">http://www.utasker.com/docs/uTasker/uTaskerSMTP.PDF</a>

The SMTP configuration can be performed on this web page corresponding to the email provider's requirements. The page KEmailSetup.htm has been loaded in place of Kadmin.htm (from the directory

\Applications\uTaskerV1.4\WebPages\WebPagesSAM7X\AlternativePages)

🥹 µTasker - Email Setup - N	Aozilla Firefox							
<u>File Edit View History</u>	<u>B</u> ookmarks <u>T</u> ools <u>H</u> elp	0						
🔇 💽 - C 🗙	http://192.168.0.3/K	EmailSetup.htm?ss 🏠 🔹 📴 Google 🔎						
Tasker - Email configuration								
1	SMTP server require	es authentication						
Image: Source of the second state o								
<i>w</i> a 3	User password							
Image: Integration     Image: Imag								
//T90	User's Email address	Setup.htm?ss A Google P I configuration Ithentication Ier name Iddress@uTasker.com provider.com 0.0.0 IIIIIIIIIIIIIIIIIIIIIIIIIIIIIII						
per agi	SMTP server address	mail.provider.com						
	SMTP server IP address	0.0.0						
User password User's Email address MyAddress@uTasker.com SMTP server address mail.provider.com SMTP server IP address 0.0.0 Save settings Go back to menu page								
Done								

Figure 11. µTasker web server showing the Email configuration page

#### V1.4

### 7.9. Dynamic Content Generation Side

The alternative web page E\_multiplication\_table.htm (from \Applications\uTaskerV1.4\WebPages\WebPagesSAM7X\AlternativePages) replaces the statistics page and demonstrates a multiplication table which is generated on demand..

For full details of this operation see the document

http://www.utasker.com/docs/uTasker/uTaskerV1.3 Content Generation.PDF



Figure 12. Dynamically generated multiplication table

# 8. Developing – Testing - Debugging

The demo project is designed to demonstrate a typical use of the operating system and TCP/IP stack. It is useful in itself as a starting point for many applications and this section looks at the support for developing, testing and debugging your own applications.

Until now you haven't actually had to develop anything since the project is delivered fully functional. To develop your own project it will be necessary to make configuration changes to suit your own use, to modify existing code and add new code of your own. To learn more about these aspects it is possible to study the documentation about the  $\mu$ Tasker operating system and protocol stack. A more hands on approach is also possible by letting the demo project run and walking through the code parts which you are interested in – we did this briefly at the start of the demo but didn't linger to discuss any details. Here we will check out the advantages of the simulator by looking in more depth at a rather more complicated debugging session.

Debugging is performed for a number of reasons. It is a natural consequence of the test phase where unexpected program behaviour is experienced and the causes and reasons need to be understood before correcting the code. It is often also an integral part of the test phase itself when code reviews are performed, exception handling is to be exercised or software validation is required. The simulator allows a high degree of tests to be performed in comfort before going to the target testing phase, where such reviews would be rather more complicated.

So let's test something in the demo project. We'll test the simple PING ECHO utility which we already used once and we'll see how we can get to know the software in a very convenient and efficient manner. We will see how we can manipulate the operation to test and validate special cases and to make corrections in the code (and verify them too). First we will work ON LINE with the simulator, meaning that the simulator will be running effectively in real time and we will capture and analyse events. Afterwards we will see how to do the same OFF LINE, using a recording of the first case (which could also be a recording made when using a real target).

#### Introducing Wireshark

If you are using the  $\mu$ Tasker then you will certainly be wanting to make use of its network capabilities and a tool to monitor network activity is essential. These are often called Network Sniffers since they can monitor, record and analyse network activity by watching what happens on the local Ethernet connection. The  $\mu$ Tasker was designed with and around Wireshark (previously called Ethereal), a free and powerful network Sniffer. You can download this from <a href="http://www.wireshark.org/">http://www.wireshark.org/</a>

If you haven't this program then don't delay – download it and install it and then we will get down to some work.

Now do the following steps:

1. Start the demo project simulation as described in the first tutorial.

2. Open a DOS window and prepare the PING command "ping 192.168.0.3".

3. Start Wireshark and start monitoring the traffic on your local network (Capture | Start -> OK).

4. Enter return in the DOS windows so that the PING test is started.

5. Wait until the PING test has completed; there are normally 4 test messages sent.

6. Stop the Wireshark recording and save it to the directory

Applications\uTaskerV1.4\Simulator\Ethereal\ with the name ping.eth

At this stage you can also look at the contents of the Wireshark recording and you will see something like the following:

No.	Time	Source	Destination	Prot	Info
1	0.437770	192.168.0.100	Broadcast	ARP	Who has 192.168.0.3? Tell192.168.0.100
2	0.439926	00:11:22_33:44:5	5 192.168.0.100	ARP	192.168.0.3 is at 00:11:22:33:44:5
3	0.439933	192.168.0.100	192.168.0.3	ICMP	Echo (ping) request
4	0.449898	192.168.0.3	192.168.0.100	ICMP	Echo (ping) reply
5	1.441345	192.168.0.100	192.168.0.3	ICMP	Echo (ping) request
6	1.441650	192.168.0.3	192.168.0.100	ICMP	Echo (ping) reply
7	2.442782	192.168.0.100	192.168.0.3	ICMP	Echo (ping) request
8	2.442915	192.168.0.3	192.168.0.100	ICMP	Echo (ping) reply
9	3.444225	192.168.0.100	192.168.0.3	ICMP	Echo (ping) request
10	3.444344	192.168.0.3	192.168.0.100	ICMP	Echo (ping) reply

It is also very possible that there are other frames on the network from other computers or your own computer talking with others, and it is possible to perform many filtering functions to remove these either from the visible display or from the recoding file – just look in the Wireshark Help.

Here my PC has the local address 192.168.0.102 and initially doesn't know how to find the destination 192.168.03. An ARP resolve is sent and the simulator responds to it, informing at which MAC address its IP can be found at.

The ping test is repeated four times, each time receiving a reply from the simulator.

So let's see in some more detail how we can check the operation of this procedure and we will begin at the deepest point in the code, the receiving interrupt routine in the Ethernet driver, which is called when a complete Ethernet frame has been received.

In the VisualStudio project, locate the file SAM7X.c (in hardware\SAM7X) and search for the Ethernet reception interrupt routine called *EMAC\_Interrupt()*. In fact this interrupt routine is common to all Ethernet interrupts so put a break point in the part which detects that the RCOMP flag has been set by positioning the cursor over the appropriate line of the routine and pressing F9.

It may be that you will find the code stopping at this break point before starting the ping test, which is probably because the code is receiving broadcast frames from your network. If this happens before you start the ping test just press F5 to let it run again (which you may have to repeat if there is a lot of activity...).

Repeat the ping test from the DOS window and the execution will stop at the breakpoint which you set in the interrupt routine. Since there will be no answer to the ping test because our code has been stopped, the ping test(s) will fail, but we don't worry about that since we have caught the event which we are going to use to analyse the flow through the driver, memory, the operating system and the ICMP routine. Now we can get to know the code in as much detail as we want....and since we are working with the SAM7X, this will also give us the opportunity to look at some of its internal registers on the way.

#### A. Interrupt routine

```
interrupt void EMAC_Interrupt(void)
 unsigned long ulInterrupts;
 while (ulInterrupts = EMAC_ISR) { // read the interrupt status register, which
                                     clears all interrupts
  if (ulInterrupts & TCOMP) { // frame tramsmitted
          ...
   ļ
  if (ulInterrupts & RCOMP) { // complete reception frame available
    ((ETHERNETQue*)(eth_rx_control))->ETH_queue.chars =
    (QUEUE_TRANSFER) (ptrRxBd->bd_details & BD_INFO_LENGTH_OF_FRAME_MASK);
                                  // put the length of the received frame
                                      in the buffer
    fnWrite(INTERNAL_ROUTE, (unsigned char*)EMAC_RX_int_message, HEADER_LENGTH);
                                  // Inform the Ethernet task
  }
  ulInterrupts &= ~(TCOMP | RCOMP);
 }
```

The simulator has just received a frame for our MAC address or a broadcast address (the simulator doesn't disturb us with foreign MAC addresses when the EMAC in the SAM7X has not be set up for promiscuous operation) and here we are in the interrupt routine. Now don't forget that this is the real code which will operate on your target and if this doesn't work properly it will also not work properly on your target.

We see that such routines are necessarily quite hardware specific. Here we see accesses to the internal register, EMAC\_ISR. Search for this registers in the SAM7X data sheet if you want to read exactly how it works; here is a very quick overview where we will also look at the registers in the simulated SAM7X.

EMAC\_ISR is the interrupt status register in the EMAC. We can search for it in our project by using "search in files", ensuring that the search path starts at the highest level in the  $\mu$ Tasker project, and using the search files of type \*.c and \*.h.

It will be found in the code at several locations but also in the file sam7x.h, where it is defined as:

#define EMAC\_ISR \*(volatile unsigned long\*)(EMAC\_PERIPHERAL\_BLOCK + 0x24)
where EMAC\_PERIPHERAL\_BLOCK is also defined locally twice:
 #define EMAC\_PERIPHERAL\_BLOCK ((unsigned char \*)(&ucSAM7x.ucSimMAC)) and
 #define EMAC\_PERIPHERAL\_BLOCK 0xFFFDC000

On the target the register is located at long word address 0xFFFDC000 and when simulating it can be found in a structure called ucSAM7X.

Double click on the word ucSAM7X so that it becomes highlighted and then drag it into the watch window (Shift F9 opens a quick watch window). Expand the structure by clicking on the cross to the left of the name and you will see the various internal peripheral divided into sub-blocks. EMAC\_ISR is in the sub-block usSimMAC so we also expand this sub-structure by clicking on the cross left of its name.

In the sub-block you will see all of the EMAC registers listed in the order in which they occur in memory as well as showing their present values. Step the code (F10) and you will see that the length of the received frame is read from a location from memory pointed to by the present EMAC buffer description and saved before sending an internal message defined by static const unsigned char EMAC\_RXA\_int\_message[ HEADER\_LENGTH ] = { 0, 0 , TASK\_ETHERNET, INTERRUPT\_EVENT, EMAC\_RXA\_INTERRUPT };

This internal message is sent to TASK\_ETHERNET to inform that a frame has been received and is as such a method used by the operating system to wake up this Ethernet task. If you want to, you can also step into the write function to see the internal workings of how it wakes up the receiver task but I will assume here that all is working well and will just move to TASK\_ETHERNET to see it actually receiving this interrupt message.

Before doing the next step, remove the break point in the interrupt routine by setting the cursor to its line and hitting F9.

#### B. Receive Task

Now open the file ethernet.c in the project directory TCP/IP and set the cursor to the bracket after the tasks routine void fnTaskEthernet (TTASKTABLE \*ptrTaskTable)

With a right click, the menu item "*Run to cursor*" can be executed and you will see that this task is indeed started immediately since the program execution stops at this line.

Step slowly through the code using F10 and observe that the task reads the contents and interprets it as an INTERRUPT\_EVENT. It calls fnEthernetEvent() to learn about the length of the received frame and to get a pointer to it – use F11 to step into this routine if you would like to see its internal workings, which I will not discuss here.

You will see that the pointer to the frame is called rx\_frame and it is defined as a pointer to an ETHERNET\_FRAME. Now, as we all know, a pointer is just a pointer – but the fact that it is defined as a pointer to a certain structure will help us greatly to interpret the contents of the received frame. We will first look at the frame as it is in memory and then how it looks in the debugger as a structure.

#### C. Receive Frame

Let's start with simply looking at the raw data which we have just received from the Ethernet. Do this by placing rx\_frame in a watch windows and expanding it so that the length of the frame (frame\_size) and the pointer to the data (ptEth) are visible [do you recognise the length from earlier?]. ptEth has a value which you can double click on and insert to the clip board before pasting it into the address field of a memory display window (if this window is not yet visible, activate it in the debug menu). Now you will see the raw Ethernet frame in memory – note that this is in the local computer's memory and the address of its location has nothing to do with the storage place on the real target.

Now it is not exactly easy to understand the data but you should just be able to make out the MAC address at the beginning and the content of the ping test usually consists of abcdefghijk... which is easily recognised. (Warning: it is possible that the frame which you actually captured is not the ping test but some other network activity, or even an ARP frame if the PC sending the ping had to re-resolve its MAC address. If this happens to be the case, set a break point at the location which the program is at and let it run again and hopefully it will come to this location the next time with the correct contents...).

Go back to the watch windows where the structure of  $rx\_frame$  is being displayed and expand the sub-structure ptEth. This will start making life rather easier since it is showing us that the Ethernet frame is made up of a destination MAC address, a source MAC address, an Ethernet frame type and some data. Expand each sub-structure to see their exact contents, although it is not yet worth expanding the data field since we don't know what protocol its contents represent so it will not be displayed better at the moment.

Name	Wert	Adresse:	0x00457c1e	
💾 📮 rx_frame	{}	 00457015	, 	E 4 D
- frame_size	0x004a	00457016	2 45 00 00 3C	- <u>First</u> 🔊
└⊟ ptEth	0x00456a40	00457C26	80 01 1B DA	iÓ
- ethernet_destination_MAC	0x00456a40 ""	00457C2A	CO A8 00 66	À''.f
[ [ 0x0]	0x00 ''	00457C2E	CU A8 00 03	A .
0x1]	0x00 ''	00457C36		
	0x00 ''	 00457C3A	61 62 63 64	abcd
	0x00 ''	 00457C3E	65 66 67 68	efgh
	0×00 ''	 00457C42	69 6A 6B 6C	ijkl
	0×00 ''	 00457C48	71 72 73 74	arst
L ethernet source MAC	0+00456=46 ""	 00457C4E	75 76 77 61	uvwa
	000 ''	 00457C52	2 62 63 64 65	bode
		 00457C56	66 67 68 69	fghi
	UXUD I	 00457058	A 41 43 41 43 7 41 43 41 43	ACAC
[ ] [ [ 0x2]	Oxdb 'U'	 00457056	2 41 43 41 43	ACAC
[ [ 0x3]	0xe6 'æ'	00457066		À
- [0x4]	0x90 '∎'	00457C64	00 01 00 00	
- [0x5]	0x2b '+'	 00457C6E	00 00 00 00	
- ethernet frame type	0x00456a4c "∎"	 00457C72	2 00 00 00 00	
	009 '	 00457C76		
		 00457078		
	UXUU	 00457076		
L⊞ ucData	0x00456a4e "E"	 00457086		
		00457C84		
		00457C8E	00 00 00 00	

#### D. Frame protocol

Step slowly using F10 and you will see that the frame is check for the ARP protocol, which it won't be if it is the ping request which we are analysing. It then calls fnHandleIP(), which we will enter using F11 since all such TCP/IP frames are built on the IP protocol.

After a couple of basic checks of IP frame validity, the pointer received\_ip\_packet is assigned to the data part of the received frame. Again this structure is very valuable to us since it can be dragged into the watch windows and now we suddenly understand how the IP fields are constructed. We can expand any field we want to see, such as the IP address of the source sending the IP frame. Note that when looking at IP frames is may be worth requesting the debugger to display the contents in decimal rather than in hexadecimal by using right click and then selecting the display mode. The IP addresses are then better understandably and afterwards you can set the mode back to hexadecimal display since it is better for most other data fields.

V1.4

lame	Wert	~	×	Adresse:	0x00457c1	3		_
📮 received_ip_packet	0x00456a4e		14		, 7 45 00	00.20	E /	
— version_header_length	69 'E'		L	00457C11	2 45 00 2 9D 2D		E<	ł
differentiatedServicesField	10''		L	00457C26	5 80 D1	1B DA	Ú	
- total_length	0x00456a50 ""		L	00457C22	A CO A8	00 66	À∵.f	
- [0x0]	0 ''		L	00457C2E	E CO A8	00 03	A	
[0x1]	60 '<'		L	00457C3	2 00 00 5 02 00	02 00		
- identification	0x00456a52 "∎0"		L	00457C32	Ā 61 62	63 64	abcd	
 	157 '		L	00457C3E	E 65 66	67 68	efgh	
[0v1]	48 '0'		L	00457C42	2 69 6A	6B 6C	ijkl	
			L	00457046	5 5D 5E 1 71 72	5F /U 72 74	mnop	
	0X00436834		L	00457C41	$\overline{z}$ 75 76	77 61	uvwa	
	U		L	00457C52	2 62 63	64 65	bode	
- [0x1]	0 ''		L	00457C56	5 66 67	68 69	fghi	
— time_to_live	128 ' '		L	00457C54	A 41 43	41 43	ACAC	
— ip_protocol	1 '		L	00457C5	E 41 43	41 43	ACAC	
🖯 ip_checksum	0x00456a58 "∎×À		L	0045706	2 41 43 5 41 00	41 43	ALAL A	
	27 '1'		L	00457C6	41 00 4 00 01		н	
	215 '×'		L	00457C6E	E 00 00	00 00		
- source IP address	0x00456a5a "à``"		L	00457C72	2 00 00	00 00		
	192 'à'		L	00457C76	5 00 00 	00 00		
	1/0 !!!		L	00457078	4 UU UU 7 NN NN			
	100		L	00457082	2 00 00	00 00		
— [Ux2]	U		L	00457C86	5 00 00	ÕÕ ÕÕ		
└── [0x3]	102 'f'		L	00457C84	A 00 00	00 00		
- destination_IP_address	0x00456a5e "À`'"		L	00457C8	E 00 00	00 00		
[0x0]	192 'À'		L	00457C92	2 00 00	00 00		
	168 '`''		L	00457096		00 00		
	0 ''			00457092	100 00 TU 100 00 T			
	 2 '∎'			00457CA2	2 00 00	00 00		
[UX3]				00457CA6	5 00 00	00 00		
-# 1p_options	UXUU456a62 " "			00457CA	A 00 00	00 00		
		<b>~</b>	1	00457CAH	E 00 00	00 00		

If you continue to step through the routine you will see that the IP frame is interpreted to see whether we are being addressed, it may cause our ARP cache to be updated and the check sum of the IP frame will also be verified. To return without stepping all the way you can use SHIFT F11 to return to the ETHERNET task code, where the protocol type is checked.

#### E. ICMP Handling

Note that each protocol type can be individually activated or deactivated in config.h. ICMP frames are only handled when the define USE\_ICMP is set. If your project doesn't want to support ICMP then it can be simply removed...

Step into the ICMP routine (fnHandleICP()) by using F11. You will see that there is also a checksum in the ICMP field which is verified and the structure ptrICP\_frame allows the ICMP fields to be comfortable viewed in the watch window.

Our frame should be of type ECHO\_PING, which can also be individually deactivated in your project if you want to support ICMP but do not want the ping test to be replied to.

The received frame is sent back, after modifying a few fields, using the call fnSendIP(). I don't want to go into details about how the IP frame is constructed – you can see this in detail by stepping into the routine and observing what happens – but I should mention how the frame is sent out over the Ethernet since this is again a low level part which uses the SAM7X registers again. Very briefly you should understand that the SAM7X has been set up with one transmission buffer into which the data is copied. The data is set up to respect the ICMP, IP and Ethernet layers as we observed in the received message and, once completely ready, the transmission is activated.

This transmission activation takes place in the file sam7x.c in the function fnStartEthTx() so search for it and set a break point there. Once the program reaches this point it will stop and you can see which registers are set up and verify that all is correct.

Here you will also see that the simulator comes into play once the data is ready and the registers have been set up correctly. This code, which will not be discussed here, basically tries to behave as the EMAC transmitter does by interpreting the register set up and transmitting the data buffer contents to your local network.

# 9. Off-Line Simulation

Normally the simulator, or the target, will have responded to the ping request very quickly and the ping test would have been successful. We, being human beings, are rather slow and we probably took several minutes to work our way through the code before your ping reply was finally sent back. This was of course much too late as the ping test has already terminated, informing that the test failed.

This is not only a problem with the ping test but with many protocols since they use timers and expect replies within quite a short time, otherwise an error is assumed and links break down. Debugging of such protocols can become quite hard work due to this fact.

This is where the  $\mu$ Tasker can save the day again since it supports operation in OFF-LINE mode. This means simply that it can interpret Wireshark recordings as if they were real data from the network. Since we previously made a recording we can try this out right now!

#### A. Prepare a break point

I suggest that you set a break point in the ICMP routine itself since we have already seen how the message arrives there ad this will avoid false triggers due to broadcast frames in the mean time. Let the project run again by hitting F5.

B. Open the Wireshark recording

In the menu Wireshark select Load Wireshark/Ethereal file to play back. Then select the ping.eth file which was previously recorded. If the simulation is repeated, the command Replay last File can be used instead – this is only valid after the simulator is terminated normally.

Perform this action and the Wireshark file will be interpreted. The times that frames arrived will be respected – if there is a gap or 1s between two frames then these two frames will also arrive with a 1s gap. You will see that the recorded ping will be received via the receive Ethernet interrupt routine and be passed up through the software until the breakpoint in the ICMP routine is encountered. The difference is that the break point and stepping in code can not disturb the protocol since also the recording is stopped.

This can be a great advantage when debugging protocols!

Before terminating this discussion there are a few points which should be noted, so here is a list of all relevant details which could be of use or interest.

- 1. When an Wireshark recording is played back, the internal NIC is closed so that there is no disturbance from the network.
- 2. The Wireshark recording can be repeated after it has terminated. There is no limit as to the number of times it can be repeated. Useful for incremental testing of a new piece of code...
- 3. After an Ethernet playback it is necessary to restart the simulator to use the simulator with the network again.
- 4. If you find a software error when stepping through the code, there is nothing to stop you making a correction without terminating the simulation session. Often VisualStudio can recompile the new code and continue with the debugging session, thus allowing the correction to be immediately used this is a major advantage of the VisualStudio environment! Try it and you will learn to love it...
- 5. Wireshark recordings do not have to originate from the simulator, they can be recordings from targets or from foreign devices. This means that recordings of a good known sequence can also be used as input to developments (for example the recording of an email being collected by your PC).

It is necessary that the simulator is set up to have the same IP and MAC addresses as the device in the recording and it will then receive all recorded frames to that device. Using this recording it is then possible to develop new code, verifying that it reacts as the original device did at each step.

Using this method, it is even possible to develop quite complicated protocols or services using a known good case as a reference. It can be basically tested before being switched onto the network so that there is a good chance that it will even work first go!

# 10. Conclusion

This tutorial first introduced the  $\mu$ Tasker simulator's capabilities to execute the demo project software on a simulated SAM7X. It showed the basics of working with the simulator and its Ethernet capabilities before turning attention to running the same project on a target board.

By working with Wireshark and the  $\mu$ Tasker simulator's ability to play back Wireshark recordings through its complete software code, interesting methods for increasing development, debugging and test efficiency have been demonstrated.

The SAM7X project supports various other features including USB. All features can be simulated using similar built-in techniques, thus enabling all aspects of real-world embedded projects to be performed with increased efficiency in comparison with convention development and debug techniques. Combining the  $\mu$ Tasker simulator with the features of the  $\mu$ Tasker demo project represents the fastest method of starting and completing embedded projects with the supported devices.

Change history:

0.01/4.2.2007: Provisional first draft - .Updated for the V1.3 demo up to side 20. 0.02/30.05.2009: Rework with title page and review for service pack 4. 0.03/31.07.2009: Adapted for  $\mu$ Tasker V1.4 with graphical LCD demonstration.